

Gebrauchsanweisung für Historische Schwarzwald-Uhr Nr. 7401

1. Öffnen sie die Rückwand des Uhrengehäuses und entfernen sie das Papier der Glocken.
2. Schrauben sie das Holzoberteil sowie das Holzunterteil am Uhrenkasten fest.
3. Die Uhr kann nun an dem gewünschten Platz, mit einer ausreichend großen Schraube, aufgehängt werden.
4. Nun wird der Pendel an dem Gestänge (Teilpendel), welches auf der Unterseite des Uhrenkastens aus dem Langloch herauschaut aufgehängt.
5. Nachdem Sie die Uhr gerade hingehängt haben, geben Sie dem Pendel einen Stoß. Nach ein paar Minuten sollte die Uhr gleichmäßig ticken (Das Tick – Tack Geräusch des Pendels soll möglichst gleichmäßig sein).
Wenn dies nicht der Fall ist, kann dies am Teilpendel eingestellt werden. Hierzu den Teilpendel so lange nach rechts oder links drücken, bis die Uhr gleichmäßig tickt.
6. Zur Einregulierung der Ganggenauigkeit der Uhr befindet sich unten am Pendel die Pendelscheibe die nach oben oder unten verschoben werden kann.
Geht die Uhr nach - Pendelscheibe nach oben schrauben.
Geht die Uhr vor - Pendelscheibe nach unten schrauben.
7. Sollten der Glockenschlag zu leise oder zu laut sein, kann dies durch biegen der Klöppel eingestellt werden.

Directions for No. 7401

1. Remove the bag of the clock-case.
2. Remove the paper between the bells and hammers.
3. Fasten the wooden head piece and the wooden lower part.
4. Hang the clock on a wall by a big nail or screw.
5. Attach the pendulum into the metal hook, which extends from the slit in the bottom of the clock. Start the clock by swinging the pendulum. You should hear an equal Tick-Tock of the pendulum. If not push the pendulum wire to the left or the right until the Tick-Tock noise is equal.
5. To set the time , you can turn the screw of the pendulum .
If the clock gains - the disc of the pendulum must go down.
If the clock is losing time - the disc of the pendulum must go up.
6. If you want the glockenspiel to be less or more loud, bend the wires of the hammers.

Rombach & Haas

Sommerbergstraße 2 78136 Schonach, Germany
Tel: (07722)5273 Fax:(07722)7858
Schwarzwalduhrenmanufaktur email: romba@t-online.de