

## **Gebrauchsanweisung für Lackschilderuhren**

1. Öffnen Sie die Rückwand des Uhrenkastens und entfernen Sie vorsichtig das Papier welches unter der Tonfeder an der Rückwand liegt.
2. Die Ketten sind mit einem Draht und einer Tüte eingewickelt. Entfernen Sie beides.
3. Die Uhr kann nun an dem gewünschten Platz mit einer ausreichend großen Schraube (oder Nagel) aufgehängt werden.
4. Nun wird der Pendel an dem Gestänge ( Teilpendel ) welches auf der Unterseite des Uhrenkastens aus dem Langloch herausschaut aufgehängt. Danach können die beiden Gewichte in die Kettenhaken gehängt werden.
5. Nachdem Sie die Uhr gerade hingehängt haben, geben Sie dem Pendel einen kräftigen Stoß. Nach ein paar Minuten hat sich die Uhr gleichmäßig eingetickt.
6. Zur einregulierung der Ganggenauigkeit der Uhr befindet sich unten am Pendel eine Schraubenmutter.  
Geht die Uhr nach - Schraubenmutter rechts herum nach oben drehen.  
Geht die Uhr vor - Schraubenmutter links herum nach unten drehen.  
Hierzu sollte der Pendel ausgehängt werden, nach dem einhängen wie in Punkt 4 beschrieben verfahren.
7. Das Schlagwerk kann an dem seitlich angebrachten Hebel abgestellt werden.  
Hebel oben - Schlagwerk in Betrieb  
Hebel unten - Schlagwerk außer Betrieb, die Uhr läuft aber weiter.

## **Direction for Shield Clocks**

1. Open the back of the clock-case and remove carefully the paper from the wire (gong) at the back of the clock-case.
2. Remove the bag and the wire which are holding the chains together on the bottom of the clock-case.
3. Hang the clock on a wall by a big nail or screw in order to allow the weights a full drop.
4. Attach the pendulum into the metal hook , which extends from the slit in the bottom of the clock. The two weights hang into the chainhooks and start the clock by swinging the pendulum powerfull.
5. To set the time , you can turn the screw of the pendulum .  
If the clock gains - the disc of the pendulum must go down.  
If the clock is losing time - the disc of the pendulum must go up.
6. If you want to stop the clock-stroke just move that dark lever on the outside of the clock-case and push it down.

**Rombach & Haas**

Sommerbergstraße 2 78136 Schonach/Germany  
Tel: (07722)5273 Fax:(07722)7858  
Email: romba@t-online.de